

OPERATING INSTRUCTIONS

PID528

AUTOTUNE PID TEMPERATURE CONTROLLER



48 x 48

SPECIFICATIONS :

SENSOR

Sensor type	Temperature range (°C)	Resolution (°C)
J	-99 to 750	0.1
K	-99 to 1350	0.1
T	-99 to 400	1
R	-99 to 1750	1
S	-99 to 1750	1
RTD	-99 to 850	0.1

DISPLAY Type

7 segment LED

Upper Display: 10mm high

Red (Process value)

Lower Display: 7mm high

Green(Set value)

Digits

Upper: 4

Lower: 4

MAIN CONTROL CONTROL

Set1 is in PID or ON/OFF

Set2 is in ON/OFF

OUTPUT

Time Proportioning or

Linear DC

A) PROPORTIONAL BAND

0 to 400 °C (Programmable)

Cycle time : Auto/Manual

(1 to 100 sec Programmable)

B) ON/OFF CONTROL AUTO TUNE

Hysteresis from 0.1 to 99.9°C

Via Keys on front Panel

MANUAL RESET

For 1° resolution- 99 to 99 °C

For 0.1 ° : -99.9 to 99.9 °C

ACCURACY

± 0.25 % of full scale/ ±1°C

(Whichever is greater)

*SET POINT LIMIT RELAY ACTION

High limit settable by user

a) Forward- for Cooling

b) Reverse - for Heating

⚠ CAUTION:

- The equipment shall not be installed in environmental conditions other than those specified in this manual.
- Fuse Protection The equipment does not contain built-in fuse. Installation of external fuse for electrical circuitry is highly recommended. Recommended rating of such fuse is supposed to be 275 VAC/1 Amp.

- Since this is a built-in-type equipment (finds place in main control panel), its output terminals get connected to host equipment. Such equipment shall also comply with basic EMI/EMC and safety requirements like BS EN 61326-1 and BSEN 61010 respectively.

- Thermal dissipation of equipment is met through ventilation holes provided on chassis of equipment. Such ventilation holes shall not be obstructed else it can lead to a safety hazard.


- The output terminals shall be strictly loaded to the manufacturer specified values/range.

INSTALLATION GUIDELINES:

Mechanical Installation:

For installing the controller

- Prepare the panel cutout with proper dimensions as shown



- Remove the clamp from the controller.

- Push the controller into the panel cutout. Secure the controller in its place by pushing the clamp on the rear side.

⚠ CAUTION:

The equipment in its installed state must not come in close proximity to any heating sources, caustic vapours, oils, steam, or other unwanted process by-products.

EMC Guidelines:

- Use proper input power cables with shortest connections and twisted type.
- Layout of connecting cables should be away from any internal EMI source.

WIRING INSTRUCTIONS:

⚠ CAUTION:

- To prevent the risk of electric shock power supply to the equipment must be kept OFF while doing the wiring arrangement.
- Terminals and electrically charged parts must not be touched when the power is ON.

- Wiring shall be done strictly according to the terminal layout with shortest connections. Confirm that all connections are correct.

- Use lugged terminals to meet M3.5 screws.

- To eliminate electromagnetic interference use of short wire with adequate ratings and twists of the same in equal size can be made.


- Cable used for connection to power source, must have a cross section of 1 or greater. These wires should have insulation capacity made of at least 1.5KV.

MAINTENANCE:

- The equipment should be cleaned regularly to avoid blockage of ventilating parts.

- Clean the equipment with a soft cloth. Do not use Isopropyl alcohol or any other cleaning agent.


TERMINAL CONNECTIONS:



TERMINAL DESCRIPTION	NO.
LIVE (SUPPLY)	1
NO of relay 2	2
COM of relay 2	3
NO of relay 1	4
COM of relay 1	5
NEUTRAL (SUPPLY)	6
Positive of thermocouple or RTD1 (Pt100)	7
Negative of thermocouple or RTD2 (Pt100)	8
Third wire of RTD (PT-100)	9

CONNECTION DIAGRAM :

1) FOR THERMOCOUPLE



Connect Thermocouple (T/C) according to polarity shown.
Positive of TC at terminal no 7 &
Negative of TC at terminal no 8


2) FOR RTD (PT-100) 2 WIRE / 3 WIRE

- 1) FOR 2 WIRE PT-100: Short terminals 8 & 9. Connect PT100 between terminal no. 7 & 8
- 2) FOR 3 WIRE PT-100: Connect RTD1 & RTD2 of 3 wire PT100 to terminal no. 7 & 8. Connect RTD3 of 3 wire PT100 to terminal no. 9.



TYPICAL CONNECTIONS FOR LOADS :

- 1) For load current less than 0.5A
- 2) For bigger loads; use interposing relay/contacter.



NOTE: Use snubber as shown above to increase life of internal relay of temperature controller.

CONFIGURATION SCHEME (parameter setting)

To enter configuration: Press **▲ & ▼** for 3 seconds.

Key press	Display		Name	Description
	Upper	Lower		
Press ▲ + ▼ for 3 sec.	5555	0000	Set Point 2	-99 to max. range of sensor for 1°C resl / -99.9 to 999.9 for 0.1°C resl
Press ▲	EUNE	OFF	* Tuning mode	Autotune : To tune the instrument select Tune (EUNE) and come out of config. Tune LED will blink indicating tune is in progress
Press ▲	MANL	00	* Manual reset	Programmable from -99.9 to 99.9 for 0.1°C
Press ▲	LOCE	0000	* Config lock code	Fixed Lock Code : 0085. Reiter user guide for explanation
Press ▲	INPE	J	Input sensor	Select input sensor type options: J (J) / K (K) / I (I) / R (R) / S (S) / RTD (RTD)
Press ▲	RESL	1	Display resolution	Resolution 0.1 or 1°C [Valid only for J (J) / K (K) / R (R) / S (S) / RTD (RTD)]

Press ▲	PLYI	PE	Select reverse (PE) for heating & forward (PE) for cooling application	Output mode of relay 1	PE	Reset	Reset all parameters to default values. Toggle between (PE) / (PE) with each press of ▲ + ▼ keys
Press ▲	PLY2	PE	Select reverse (PE) for heating & forward (PE) for cooling application	Output mode of relay 2	PE	Reset	Reset all parameters to default values. Toggle between (PE) / (PE) with each press of ▲ + ▼ keys
Press ▲	SELE	RES	Absolute/Deviation Toggle between (RES) / (RES) mode by pressing of ▲ + ▼ keys	Set Point 2	RES	Reset	Reset all parameters to default values. Toggle between (PE) / (PE) with each press of ▲ + ▼ keys
Press ▲	HYS2	010	Programmable from 0.1 to 99.9°C	Hysteresis of Set2	010	Reset	Reset all parameters to default values. Toggle between (PE) / (PE) with each press of ▲ + ▼ keys
Press ▲	Pb	010	Proportional band programmable from 0.0 to 400.0 °C	Proportional band	010	Reset	Reset all parameters to default values. Toggle between (PE) / (PE) with each press of ▲ + ▼ keys

Note : To operate in ON/OFF mode make Pb = 00

Key press	Display		Name	Description
	Upper	Lower		
Press ▲	INTE	0120	Integral time	Integral time (reset) programmable from 0 to 3600 sec. This parameter is prompted only in PID mode. i.e. When PBS=0
Press ▲	DETE	030	Derivative time	Derivative time (rate) programmable from 0 to 200 sec. This parameter is prompted only in PID mode. i.e. When PBS=0
Press ▲	CYC	020	Cycle time	Range: 1 to 100 sec
Press ▲	HYS1	010	Hysteresis of Set1	Valid only for ON/OFF mode Programmable from 0.1 to 99.9
Press ▲	HtLH	0750	High Level Limit	Select the maximum limit of setpoint.
Press ▲	LSPI	010	Lock setpoint	Lock setpoint1 Toggle between (PE) / (PE) with each press of ▲ + ▼ keys
Press ▲	LSPI2	010	Lock setpoint	Lock setpoint1 Toggle between (PE) / (PE) with each press of ▲ + ▼ keys


Press ▲	SELE	Reset	Reset all parameters to default values. Toggle between (PE) / (PE) with each press of ▲ + ▼ keys
Press ▲ + ▼ for 3 sec.	to come out of programming.		

NOTE: * mark explain in user guide.

Programming Set Point	
A) To view set point : Press ▲ key	
B) To increase / decrease set point : Press ▲ + ▲ / ▼ + ▼	
Continuous operation of above makes update speed faster in 3 stages after 7 seconds.	


USER GUIDE:

- 1. **ON/OFF control action (For heating):** The relay is 'ON' up to the set temperature and cuts 'OFF' above the set temperature. As the temperature of the system drops, the relay is switched 'ON' at a temperature slightly lower than the Set point.



- HYSTERESIS:** The difference between the temperature at which relay switches 'ON' and at which relay switches 'OFF' is the hysteresis or deadband.


- 2. **Time proportional control:** In time proportional control, the relay 'ON' time and relay 'OFF' time varies in proportion to the deviation of the actual temperature from the set value. The proportional action occurs within a band about the set point. The proportional mode of control gives closer control than ON/OFF type.



- 3. **Off set adjustment (manual reset):** After some time the process temperature settles at some point and there is a difference between the set temperature & the controlled temperature. This difference can be removed by setting the manual reset value equal & opposite to the offset.

- 4. **Auto tuning:** The auto tuning function automatically measures, compute and sets the proportional band (P), integral time (I) and Derivative time (D). While Auto tuning, the controller performs proportional control and determine proper P.I.D. Values.


PID - time proportioning with auto reset & rate



5. Set point limit:

All set points are programmable from low to high limit. For 0.1° resolution set points are programmable from low to high limit between -99.0 to +999.9°C/°F

- 6. **Configuration lock code:** To enable configuration lock first remove the housing and then remove the jumper J1. To scroll through next functions set lock = 0085.



WARRANTY / LIMITATIONS OF LIABILITY

Selec Controls USA., Inc. warrants the products to be free from defects in the materials and workmanship for a period of one year (or other period specified, if any) from the date of sale by Seleco.

The warranty does not apply to defects resulting from any action of the buyer, including but not limited to improper handling, operating the product outside the specification limits, or unauthorized disassembling / altering of the product. The warranty shall be VOID if the product shows evidence of having been tampered or being damaged due to usage in corrosive environment; or current, heat, moisture or vibration; improper specification; wrong usage in an application; misuse or other operating conditions outside of Seleco's control.

Selec shall not be responsible for special, indirect or consequential damages, loss of profits or commercial loss in any way connected with the products, whether such claim is based on contract, warranty, negligence or strict liability.

In no event shall the responsibility of Seleco for any act exceed the individual price of the product on which liability is asserted.

In no event shall Seleco be responsible for warranty or other claims regarding the products unless Seleco's analysis confirms that the products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse, or inappropriate modification or repair.

CALIBRATION CERTIFICATE

Date: _____

Model No.: _____

Sr. No.: _____

Claimed Accuracy:
± 0.25% of full scale ±1 digit (After 20min warmup time)

Sources calibrated against:
Hinditron Multimeter Model 86, Sr. No.:1094

Multimeter calibration report no.:
ERTL(W), Mumbai, INDIA

The calibration of this unit has been verified at the following values:

SENSOR	CALIBRATION TEMP (°C) (0.1 resolution)	DISPLAY VALUE (°C)
K	35.0	35.0
	700.0	700.0
	1350	1350
PT100	0.0	0.0
	500.0	500.0
	800.0	800.0

The thermocouple / RTD curves are linearised in this microprocessor based product; and hence the values interpolated between the readings shown above are also equally accurate; at every point in the curve.

Unit is accepted as accuracy is within the specified limit of claimed accuracy and certificate is valid upto one year from the date of issue.

CHECKED BY: _____

(Specifications subject to change as development is a continuous process).

Selec Controls USA., Inc.

203 Main Street, #205
Flemington, NJ 08822, USA
Website: www.selecusa.com
E- mail: sales@selecusa.com