

MINIATURE TOGGLE SWITCH

MTS-102-A2 ON-ON
MTS-112-A2 ON-(ON)
MTS-103-A2 ON-OFF-ON
MTS-113-A2 ON-OFF-(ON)
MTS-123-A2 (ON)-OFF-(ON)
 SPDT 3P

KNX-1 ON-ON
KNX-103 ON-OFF-ON
 SPDT 3P

MTS-201-A2 ON-OFF
 DPST 4P

KNX-2 ON-ON
KNX-203 ON-OFF-ON
 DPDT 6P

MTS-202-A2 ON-ON
MTS-212-A2 ON-(ON)
MTS-203-A2 ON-OFF-ON
MTS-213-A2 ON-OFF-(ON)
MTS-223-A2 (ON)-OFF-(ON)
 DPDT 6P

STM-101 ON-OFF
 SPST 2P

MTS-302-A2 ON-ON
MTS-303-A2 ON-OFF-ON
 3PDT 9P

STM-102 ON-ON
STM-112 ON-(ON)
STM-103 ON-OFF-ON
STM-213 ON-OFF-(ON)
STM-223 (ON)-OFF-(ON)
 SPDT 3P

MTS-102-A2T ON-ON
MTS-112-A2T ON-(ON)
MTS-103-A2T ON-OFF-ON
MTS-113-A2T ON-OFF-(ON)
MTS-123-A2T (ON)-OFF-(ON)
 SPDT 3P

STM-202 ON-ON
STM-212 ON-(ON)
STM-203 ON-OFF-ON
STM-213 ON-OFF-(ON)
STM-223 (ON)-OFF-(ON)
 DPDT 6P

MTS-202-A2T ON-ON
MTS-212-A2T ON-(ON)
MTS-203-A2T ON-OFF-ON
MTS-213-A2T ON-OFF-(ON)
MTS-223-A2T (ON)-OFF-(ON)
 DPDT 6P

MTS-101-L1 ON-OFF

MTS-102-C3 ON-ON
MTS-112-C3 ON-(ON)
MTS-103-C3 ON-OFF-ON
MTS-113-C3 ON-OFF-(ON)
MTS-123-C3 (ON)-OFF-(ON)
 SPDT 3P

KN3(C)-101 ON-OFF
KN3(C)-101A ON-OFF
 SPST 2P

MTS-202-C3 ON-ON
MTS-212-C3 ON-(ON)
MTS-203-C3 ON-OFF-ON
MTS-213-C3 ON-OFF-(ON)
MTS-223-C3 (ON)-OFF-(ON)
 DPDT 6P

KN3(C)-102/102A ON-ON
KN3(C)-112/112A ON-(ON)
KN3(C)-103/103A ON-OFF-ON
KN3(C)-113/113A ON-OFF-(ON)
KN3(C)-123/123A (ON)-OFF-(ON)
 SPDT 3P

MEDIUM TOGGLE SWITCH

<p>KN3(C)-201 ON-OFF KN3(C)-201A ON-OFF DPST 4P</p>	<p>KN3(B)-101 ON-OFF KN3(B)-101A ON-OFF SPST 2P</p>
<p>KN3(C)-202/202A ON-ON KN3(C)-212/212A ON-(ON) KN3(C)-203/203A ON-OFF-ON KN3(C)-213/213A ON-OFF-(ON) KN3(C)-223/223A (ON)-OFF-(ON) DPDT 6P</p>	<p>KN3(B)-102/102A ON-ON KN3(B)-112/112A ON-(ON) KN3(B)-103/103A ON-OFF-ON KN3(B)-113/113A ON-OFF-(ON) KN3(B)-123/123A (ON)-OFF-(ON) SPDT 3P</p>
<p>KN3(C)-101P ON-OFF KN3(C)-101AP ON-OFF SPST 2P</p>	<p>KN3(B)-201 ON-OFF KN3(B)-201A ON-OFF DPST 4P</p>
<p>KN3(C)-102P/102AP ON-ON KN3(C)-112P/112AP ON-(ON) KN3(C)-103P/103AP ON-OFF-ON KN3(C)-113P/113AP ON-OFF-(ON) KN3(C)-123P/123AP (ON)-OFF-(ON) SPDT 3P</p>	<p>KN3(B)-202/202A ON-ON KN3(B)-212/212A ON-(ON) KN3(B)-203/203A ON-OFF-ON KN3(B)-213/213A ON-OFF-(ON) KN3(B)-223/223A (ON)-OFF-(ON) DPDT 6P</p>
<p>KN3(C)-201P ON-OFF KN3(C)-201AP ON-OFF DPST 4P</p>	<p>KN3(B)-401 ON-OFF KN3(B)-401A ON-OFF 4PST 8P</p>
<p>KN3(C)-202P/202AP ON-ON KN3(C)-212P/212AP ON-(ON) KN3(C)-203P/203AP ON-OFF-ON KN3(C)-213P/213AP ON-OFF-(ON) KN3(C)-223P/223AP (ON)-OFF-(ON) DPDT 6P</p>	<p>KN3(B)-402 ON-ON KN3(B)-403 ON-OFF-ON KN3(B)-402A ON-ON KN3(B)-403A ON-OFF-ON 4PDT 12P</p>
<p>KN3(A)-101 ON-OFF KN3(A)-101A ON-OFF SPST 2P</p>	<p>KN3-1 ON-OFF 4A 125VAC; 2A 250VAC SPST 2P</p>
<p>KN3(A)-102/102A ON-ON KN3(A)-112/112A ON-(ON) KN3(A)-103/103A ON-OFF-ON KN3(A)-113/113A ON-OFF-(ON) KN3(A)-123/123A (ON)-OFF-(ON) SPDT 3P</p>	<p>KN3-2 ON-OFF 4A 125VAC; 2A 250VAC SPDT 4P</p>